



CRANK OPERATED

# Outdoor Blind

Sunblock Shade Cloth & Pelmet



5-Year Fabric  
Warranty against  
UV degradation



2-Year Parts  
Warranty

Up to  
**95%**  
UV Block

## CHARCOAL

487188 - 1.2 m x 2.4 m

487195 - 1.5 m x 2.4 m

487706 - 1.8 m x 2.4 m

487713 - 2.1 m x 2.4 m

487720 - 2.4 m x 2.4 m

## SHELL

487737 - 1.2 m x 2.4m

487744 - 1.5 m x 2.4 m

487751 - 1.8 m x 2.4 m

487768 - 2.1 m x 2.4 m

487775 - 2.4 m x 2.4 m



Retract your exterior blind when not in use, or before strong storms, to prevent damage.

## **WARNING**

When assembling and using this product, safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

Please read all instructions before assembly and use.

Two or more people are recommended for safe assembly.

Keep all children and pets away from assembly area.

Check all screws for tightness before use.

Retract your exterior blind when not in use, or before strong storms, to prevent damage.

Do not place the product near an open flame or too close to any heat source such as heaters or BBQs.

The diagrams in this manual are for illustration purposes only, to assist with assembly and operation. They may differ from the outdoor blinds actual appearance.

## **CARE AND MAINTENANCE**

Your exterior blind has been made of the finest materials and, when properly cared for, will provide years of shade, privacy and protection from the elements.

To clean your shade, simply rinse with water, scrub with mild soap or any non abrasive cleaner, rinse and allow to dry.

Do not store shade wet. In damp environments roll blind down frequently to air dry. Retract your exterior blind when not in use, or before strong storms, to prevent damage.

## **CAUTION**

Use of solvents or abrasive cleaners may damage the fabric and will void your warranty. Do not bleach or use chlorine.

## Sizes

<p><b>120</b> cm WIDTH</p> <p><b>240</b> cm DROP</p> <p>Overall width 122cm</p> <p>Charcoal - 487188 Shell - 487737</p>	<p><b>150</b> cm WIDTH</p> <p><b>240</b> cm DROP</p> <p>Overall width 152cm</p> <p>Charcoal - 487195 Shell - 487744</p>	<p><b>180</b> cm WIDTH</p> <p><b>240</b> cm DROP</p> <p>Overall width 183cm</p> <p>Charcoal - 487706 Shell - 487751</p>	<p><b>210</b> cm WIDTH</p> <p><b>240</b> cm DROP</p> <p>Overall width 213cm</p> <p>Charcoal - 487713 Shell - 487768</p>	<p><b>240</b> cm WIDTH</p> <p><b>240</b> cm DROP</p> <p>Overall width 244cm</p> <p>Charcoal - 487720 Shell - 487775</p>
---	---	---	---	---

## What's in the box

Installing your new Coolaroo Outdoor Blind is easy, simply follow our step-by-step instructions.

PARTS LIST	QTY
a Premium Pelmet	1
b Crank Handle	1
c Caps with Rings	2
d Bungee Tie Downs	2
e Bottom rail	1
f Bungee receiver	2
g Screws	10
h Quick Mount Brackets	3
i Wall Plugs	10
j Shade	1
k Template	1


## TOOLS REQUIRED

Power Drill with 5mm masonry bit  
Tape measure  
Phillips head screwdriver  
Pencil  
Spirit level



### INSIDE OR OUTSIDE MOUNT

This blind can be fitted to the top (inside) or face (outside) of your wall, depending on your installation environment.

#### Top (inside) mount



#### Face (outside) mount



# Installation

## SETTING MOUNTING POINTS USING THE TEMPLATE (k)

The unique pelmet design allows for face mounting (Fig. 1) or top mounting (Fig. 2) of the blind to suit your installation environment.

Use temporary fixing (ie. tape) to attach the Template (k) to your mounting surface - ensuring it is level. The three Quick Mount Brackets (h) can be positioned anywhere inside each of three grey areas on the template, allowing for location of timber studs, if required. There must be one Quick Mount Bracket in each of the three grey areas (Fig. 3), ensuring they are spaced far enough apart for best support and weight distribution.

Use your pencil to mark your preferred bracket positions on the template, ensuring you have allowed **50mm clearance for attachment of the pelmet**.

Fig. 1 - Face Mount




Fig. 2 - Top Mount





Fig. 3



## INSTALL QUICK MOUNT BRACKETS (h)

When fitting the brackets make sure they are positioned with the tabs pointing forward (for top mount) or downward (for face mount) (Fig. 4 and Fig. 5), to allow easy fitting and removal of the shade.

If fixing into masonry, drill a 5mm hole and insert Wall Plugs (i).

**DO NOT SCREW INTO PLASTER UNLESS YOU ARE USING SCREWS LONG ENOUGH TO FULLY PENETRATE THE TIMBER SUB-FRAME.**

Fig. 4 - Face Mount






Fig. 5 - Top Mount



Ensure the Quick Mount Brackets are orientated correctly (Fig. 6) then secure into place with Screws (g) using a Philips-Head Screwdriver.

The brackets must be positioned and installed level to ensure the blind functions properly.

Fig. 6



## INSTALL PELMET (a)

Install the Pelmet (a) by locating the tabs on each bracket into the channel on the pelmet and then snapping the housing securely into place.

NOTE : If the brackets have been installed upside down or backwards the pelmet will not fit.

# Installation

## INSTALL BUNGEE TIE DOWNS (d) (Optional)

Bungee Tie Downs can be used to help keep your shade steady in mild to moderate wind conditions.

Thread the bungee cord through the Bottom Rail End Cap (c) and back through itself making a Lark's Head Knot (Fig. 7)

Use a drill and the remaining fixings to install the Bungee Receiver (f) (Fig. 8) approximately 130mm below the bottom of where the shade will stop, to allow for adequate tension of the Bungee Tie Down (d).

Stretch the Bungee Tie Downs until they hook over the Bungee Receiver to keep the shade taught in the down position.

Note: Ensure the Bungee Tie Downs are released before raising the blind.

Fig. 7





Fig. 8



## RAISING AND LOWERING THE SHADE

Locate the hook on the Crank Handle (b) through the adjustment eyelet located on the right hand side of the pelmet (Fig. 9). Turn the Crank Handle to lower or raise the Shade (j) to the desired position (Fig. 10).

Fig. 9





Fig. 10



## HANDY TIP WHEN RAISING YOUR BLIND:

To prevent the blind from running askew when winding up, have someone hold the bottom rail to keep it taught while turning the crank handle.

# Warranty

## 5 YEAR FABRIC AND 2 YEAR PARTS WARRANTY AND LIMITATION OF LIABILITY

Coolaroo products are manufactured by Gale Pacific Limited ACN 082 263 778 (Gale). Gale provides the following warranty in relation to Coolaroo products ("Product").

The benefits of this warranty are in addition to any rights and remedies imposed by Australian Consumer Law, NZ Consumer Guarantees Act 1993, and state and federal legislation that cannot be excluded. Nothing in this warranty is to be interpreted as excluding, restricting or modifying any applicable legislation to the supply of goods and services which cannot be excluded, restricted or modified.

To register your product for warranty, go to [www.coolaroo.com](http://www.coolaroo.com).

### WARRANTY

Gale warrants that, subject to the exclusions and limitations below, all parts of the manufacture and assembly of the Product will be free from defects in materials and workmanship for a period of five (5) years fabric and two (2) years parts.

If a defect appears in the Product before the end of the warranty period and Gale finds the Product to be defective in materials or workmanship, Gale will, in its sole discretion, either:

- a) replace or repair the Product or the defective part of the Product free of charge; or
- b) refund the purchase price of the Product.

Gale reserves the right to replace defective parts of the Product with parts and components of similar quality, grade and composition where an identical part or component is not available.

The warranty will not apply where:

- a) the Product has been altered or modified by someone other than Gale or its authorised agent;
- b) the alleged defect in the Product is within acceptable industry variances;
- c) Gale cannot establish any fault in the Product;
- d) the defect in the Product has arisen due to the customer's failure to install and use the Product in accordance with the instructions provided;
- e) the defect in the Product has arisen due to the customer's request to customise the Product;
- f) the Product has been subject to abnormal conditions, including environment, temperature, water, fire, humidity, pressure, stress or similar.

The warranty does not extend to:

- a) damage or defects caused by normal wear and tear,
- b) water or sun damage; or
- c) any other damage caused by the customer placing other equipment, furniture or material in close proximity to the Product. Gale makes no express warranties or representations other than set out in this warranty.

The repair or replacement of the Product or part of the Product is the absolute limit of Gale's liability under this express warranty.

### WARRANTY CLAIMS

- 1) Upon purchasing the Product, the customer must register their warranty by completing the Coolaroo online warranty registration at [www.coolaroo.com](http://www.coolaroo.com). Alternatively, the customer can contact Coolaroo Customer Service on 1800 331 521 (AU) or 0800 555 171 (NZ) for assistance.
- 2) If a fault covered by warranty occurs, the customer must contact Gale using the contact details provided.
- 3) Any warranty claim must be accompanied by proof of purchase and details of the alleged defect.
- 4) The customer must bear the cost of the transport of the Product to and from Gale or the authorised agent to make the warranty claim, and all insurance of the Product.

### AUSTRALIAN CONSUMER LAW

Nothing in this agreement is intended to have the effect of contracting out of any applicable provisions of the Competition and Consumer Act 2010 or the Fair Trading Acts in each of the States and Territories of Australia, except to the extent permitted by those Acts where applicable.

This warranty is not transferable, and applies only to the initial purchaser of the installed Product.

In addition to the above warranty, Australian Consumer law and other state and territory legislation may imply warranties or conditions or impose liability on Gale in relation to the Product or its supply which cannot, or can only to a limited extent, be excluded, restricted or modified. Except for those implied warranties or conditions and such liability, and for the warranty described above:

- a) all warranties and conditions (whether express or implied, statutory or otherwise) relating to the Product or its supply are expressly excluded; and
- b) Gale will not be liable for any loss or damage suffered by any person (including the purchaser of the Product) in any way relating to or arising from the Product or its use (including loss or damage arising from the negligence of, or contributed to by, Gale).

If liability for breach by Gale of a warranty or condition or any other liability imposed on Gale by legislation which cannot be excluded may be limited, Gale's liability is limited to the extent permitted by law, and if liability may be limited in any one of a number of ways, Gale's liability is limited in any one of the permitted ways chosen by Gale in its absolute discretion.

The Purchaser acknowledges that the Purchaser does not rely on the skill or judgment of Gale as to whether or not the Products are fit for any particular purpose.

The Purchaser indemnifies Gale from every liability, loss, damage, cost or expense directly or indirectly incurred or suffered by Gale caused by or contributed to by the Purchaser's failure to:

- 1) adequately provide or display safety markings or safety information on or with the Products;
- 2) comply with any law about the Products or their use;
- 3) take any reasonable precaution to bring to the attention of any potential users of the Products any dangers associated with Products;
- 4) any negligence or breach of duty by the Purchaser or any breach by the Purchaser of these terms.



Australia Toll Free: 1800 331 521  
New Zealand Toll Free: 0800 555 171

© Coolaroo is a registered trademark of Gale Pacific Limited.

Made in China.